



Example of a clear-span bridge which retains the existing river channel, abutments are set back from the river bank (AT&F, 2022)





Example of a clear-span bridge, which retains the existing river channel and column set back from the river bank (National Roads Authority, 2008)

Site Name:	Project No.		Drawn By:	Colleen McClung Graduate Project Scientist	
	Client:				
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 1 Examples of Clear Span Bridge	Date:		Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant	
	Revision:	00			

Closed Culvert Good Practice Design Considerations – Section

Figure 40: Good practice, culverts showing invert buried below bed level allowing the natural bed level, slope and material to be maintained. Culvert also maintains natural channel width.



SEPA (2010) Engineering in the Water Environment Good Practice Guide – River Crossings .

Closed Culvert Good & Bad Examples – Section

Figure 41: Good practice, use a single large culvert for crossings that maintains the natural channel width.




Figure 42: Poor practice, do not use smaller multiple pipes; they can create a barrier to fish passage.




SEPA (2010) Engineering in the Water Environment Good Practice Guide – River Crossings .




TrueNorth Steel (2021)

NOTE: Coarse aggregate has been used for erosion control. Silt fencing has been used to mitigate against the entrainment and mobilisation of solids during the construction process

Roadex Network
<https://www.roadex.org/e-learning/lessons/drainage-of-low-volume-roads/components-of-road-drainage-system/>

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Sven Klinkenbergh Principal Environmental Consultant	
	Client:	Orsted Renewables Ltd			
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 2 Culverting – General Considerations	Date:	07/11/2023	Reviewed By:	SK	
	Revision:	00 DRAFT			



NO - TOO DEEP

NO - TOO HIGH

YES

Has to be 30cm, according to finnish instructions

Roadbed

30 cm min.

2 Slope 1

Seed and soil revetment or protect with ballast

Do not change stream bottom elevation!

Examples of poorly performing (above) and well built and maintained culverts (below).


Example of a well designed, built and maintained main road culvert built in relatively steep hill slope in Scotland

NOTE: Coarse aggregate will be used for erosion control. These areas at the openings of the culvert will also be designed to reduce velocity / discharge rate in turn further controlling erosion and providing additional beneficial impacts such as increased attenuation time, increased recharge to ground etc.


In line with mitigation measures – It is suggesting to install this.

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By: Sven Klinkenbergh Principal Environmental Consultant Jayne Stephens	
	Client:	Orsted Renewables Ltd		
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 3a Example of Culvert to be installed	Date:	07/11/2023	Reviewed By: SK	
	Revision:	00 DRAFT		

Section



Plan



Site Name:
Oatfield Wind Farm Project, Co. Clare


DRAFT

Project No. 604569
Client: Orsted Renewables Ltd
Date: 14/11/2023
Revision: 00 DRAFT

Drawn By: Sven Klinkenbergh
Principal Environmental Consultant
Reviewed By: SK



Figure Name:
**Appendix 9.5 – Conceptual & Information Graphics – Tile 3b
Design Considerations for Culvert & Drainage Connection**



Example of a temporary berm
 (Green Infrastructure Ontario, 2012) Available at:
<https://greeninfrastructureontario.org/infiltration-trench-swale-construction/>




Built-up berm

Conceptual graphic of an interceptor drain
 (NRCS/USDA.gov, 2007) Available at: https://www.nrcs.usda.gov/Internet/FSE_DOCUMENTS/nrcs141p2_017651.pdf

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Colleen McClung Graduate Project Scientists
	Client:	Orsted Renewables Ltd		
Figure Name: Appendix 9.5: Conceptual & Information Graphics – Tile 4 Interceptor Drain & Spoil Berms	Date:	07/11/2023	Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant
	Revision:	00		





Site Name:
Oatfield Wind Farm Project, Co. Clare


Figure Name:
**Appendix 9.5 – Conceptual & Information Graphics – Tile 5
 Collector Drains and Buffered Outfalls**

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00

Drawn By:	Colleen McClung Graduate Project Scientist
Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant



Constructed Drain and Check Dams – Section




Check Dam Design Consideration (CIRIA, 2004)

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
	Client:	Orsted Renewables Ltd		
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 6 Check Dams – General Considerations	Date:	07/11/2023	Reviewed By:	SK
	Revision:	00 DRAFT		




Constructed Drain and Check Dams – Plan View




NOTES:

- The extensive use of check dams is recommended for the following reasons:
 - Management of runoff in terms of reducing flow velocity and minimising in channel erosion, or erosion at drainage outfalls.
 - Maximise attenuation of runoff with a view to enhancing runoff quality i.e. settlement of suspended solids.
 - Maximise attenuation of runoff with a view to reducing the hydrological response to rain fall at the site.
 - Maintain or improve the site hydrological/ hydrogeological regime with a view to maximising recharge to ground and increasing groundwater levels locally. This is particularly relevant for peatland areas.
- Check dams will be constructed with the following features and specifications:
 - A low flow pipe or small orifice to allow for low flows through the check dam.
 - Check dams will be permanent (life of development) and will be constructed with crushed rock with appropriate geo-chemistry (local) for example; coarse aggregate (100-600 mm). Wooden boards, gabions can also be used.
 - Erosion protection and energy dissipaters (cobles / boulder 100-150mm diameter) which will extend approximately 1.2 – 1.8m downgradient of the dam and applied to both the base and side walls of the drain / swale.
 - Erosion control can be enhanced with the in-combination use of geotextile base layers (but consider low flow through).
 - It is recommended that the drainage channels / swales are entirely lined with coarse aggregate / erosion control. This will enhance mitigation in terms of attenuation, erosion control, and recharge to ground. Alternatively, allowing drains / swales to vegetate will achieve similar effects.

Constructed Drain and Check Dams – Section A-A'




Constructed Drain and Check Dams – Section B-B'



Site Name: Oatfield Wind Farm Project, Co. Clare	Project No. 604569	Drawn By: Sven Klinkenbergh Principal Environmental Consultant
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 7 Check Dams – General Considerations	Client: Orsted Renewables Ltd	
	Date: 07/11/2023	Reviewed By: SK
	Revision: 00 DRAFT	




Constructed Drain and Check Dams – Plan View




NOTES:

- It is recommended to align the elevation of the upgradient toe and downgradient crest. Therefore the spacing (L) of check dams will be dependent on the on the slope angle of a particular length (L) of drainage, whereby; on shallow slopes check dams will have larger spacing and on steeper slopes (up to 15 degrees *) spacing will be smaller.
- The purpose of aligning the toe and crest of respective check dams is recommended with a view to maximising pooling, or attenuation capacity of the drainage channel. The conceptual section presented here is designed with the downgradient crest (A) higher than the upgradient toe, as opposed to the crest (B) which is aligned with the toe. The purpose of this is to further enhance attenuation capacity at the dam, and to maximise hydraulic head ** and infiltration / percolation of runoff to ground water (recharge). However, this approach has limitations including for the potential to adversely impact undermine the integrity of the upgradient dam through erosion etc. or the downgradient dam through loading / excess weight. Mitigation measures including material selection, erosion control, and variable flow (V-notch) *** will be used where relevant to mitigate such impacts.
- (*) Check dams are recommended for drainage channels with slope angle up to 15 degrees. Drainage and runoff on steeper slopes (>15 degrees) will require different drainage velocity control features, for example; rock ripraps.
- (**) Attenuation of runoff in drainage channels is an opportunity to enhance recharge and reduce the hydrological response to rainfall at the site. However, detailed design will consider environmental and geological constraints, for example; enhanced re charge is not recommended in areas of elevated or high landslide susceptibility or risk.
- (***) V-Notch weirs discussed Conceptual Design – Drainage Infrastructure Check Dams – With Variable Flow Rate / V – Notch Weirs

Constructed Drain and Check Dams – Section A-A'



Constructed Drain and Check Dams – Section B-B'




Site Name: Oatfield Wind Farm Project, Co. Clare	Project No. 604569	Drawn By: Sven Klinkenbergh Principal Environmental Consultant
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 8 Check Dams – Design Specifications and Considerations	Client: Orsted Renewables Ltd	
	Date: 07/11/2023	Reviewed By: SK
	Revision: 00 DRAFT	

Drawn By: Sven Klinkenbergh Principal Environmental Consultant
Reviewed By: SK



Constructed Drain and Check Dams – Plan View


DRAIN FLOW DIRECTION




NOTES:


- V-Notch weirs can be included in designs as a control to mitigate against variable or peak flows / drainage discharge rates.
- V-Notch can also be employed to correct the elevation differential (between Toe and Crest) of respective in line check dams.


Constructed Drain and Check Dams – Section A-A'



Constructed Drain and Check Dams – Section B-B'



Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By: Sven Klinkenbergh Principal Environmental Consultant	
	Client:	Orsted Renewables Ltd		
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 9 Check Dams – With Variable Flow Rate / V – Notch Weirs	Date:	07/11/2023	Reviewed By: SK	
	Revision:	00 DRAFT		



CIRIA SuDS Manual (2015)


A swale can have check dams installed at measured intervals across the flow path, that temporarily pond runoff to increase pollutant retention and infiltration and further decrease flow velocity.

Swale channels are broad and shallow and covered by vegetation, which slows the flow of water and facilitates sedimentation as well as filtration through the roots and soil matrix, evapotranspiration and infiltration into the underlying soil.

Shallow, vegetated, open channel designed to direct, treat and attenuate surface water runoff with a potential for biodiversity benefits.




Massachusetts Department of Environmental Protection (2023)
<https://megamanual.geosyntec.com/npsmanual/checkdams.aspx>




CIRIA SuDS Manual (2015)

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Colleen McClung Graduate Project Scientist		
	Client:	Orsted Renewables Ltd		Reviewed By:		Sven Klinkenbergh Principal Environmental Consultant
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 10 Check Dams – General Considerations	Date:	07/11/2023				
	Revision:	00				




Catchments & Creeks Pty Ltd (2010)

<<https://www.catchmentsandcreeks.com.au/docs/SEP-1.pdf>>




United Nations Food and Agriculture Organization

<https://www.fao.org/fishery/docs/CDrom/FAO_Training/FAO_Training/General/x6708e/x6708e01.htm>



CIRIA SuDS Manual (2015)


Ponds should be designed to mimic natural forms and have varying depths which can provide a range of different habitats.

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Colleen McClung Graduate Project Scientist	
	Client:	Orsted Renewables Ltd			
	Date:	07/11/2023	Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant	
	Revision:	00			



- 1 WATER PUMPED INTO CLARIFIER
- 2 STILLING CHAMBER DIRECTS FLOW DOWNWARDS
- 3 FLOW DISTRIBUTED BETWEEN PLATES
- 4 SOLIDS TRAVEL DOWN PLATES AS WATER MOVES UPWARDS
- 5 OUTLET DESIGN MAINTAINS FLOW EVEN IF UNIT NOT LEVEL
- 6 SLUDGE STORED IN HOPPER

Example of an oil-water separator
 Minerex Environmental Limited, an RSK Group company




Cross-section of oil-water separator
 Mohr, Kirby S. (2014)

Siltbuster ® (2017) "Solutions for Suspended Solids Removal: Hire, Sales & Technical Support" Siltbuster Ltd. Available at: <https://www.siltbuster.co.uk/wp-content/uploads/2020/10/Solutions-for-Suspended-Solids-Removal.pdf>.

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Colleen McClung Graduate Project Scientists	
	Client:	Orsted Renewables Ltd		Reviewed By:	
Figure Name: Appendix 9.5 – Conceptuel & Information Graphics – Tile 12 Settlement Tank	Date:	07/11/2023			
	Revision:	00			


Conceptual Treatment Train Layout for Construction Areas (Access Tracks, Hardstand Areas, Turbine Base, etc.) & Clean Water By-Pass



NOTES:

- Wherever possible, outfalls will be positioned outside of Surface Water Buffer Zones.
- For areas of the development footprint within Surface Water Buffer Zones, in line measures such as silt screens will be over specified e.g. double / triple silt screens, and access to emergency intervention sump / pumps will be facilitated through design and/or emergency response.
- Quality of runoff entering buffer zones will be good i.e. suspended solids <25mg/l. Where runoff quality is poor, emergency response will be to use an intervention sump / pump and pump divert runoff to an area of the drainage network where it will be treated before redistribution and discharge.



Conceptual Treatment Train Layout for Construction Areas & Associated Infrastructure within Surface Water Buffer Zones



Site Name: Oatfield Wind Farm Project, Co. Clare	Project No. 604569	Drawn By: Sven Klinkenbergh Principal Environmental Consultant
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 13 Water Treatment Train Layouts	Client: Orsted Renewables Ltd	Reviewed By: SK
	Date: 07/11/2023	
	Revision: 00 DRAFT	



Conceptual Treatment Train Layout for HDD – Plan View



NOTES:


- This methodology and example scenario is designed with a view to managing Horizontal Drilling Arisings, but can be applied to all scenarios whereby active dewatering, treatment, or management of construction waters is required.
- Contaminated water arising from construction works, namely; excavations, drilling and temporary stockpiling, will be contained and treated prior to release or discharge. The schematic presented here is a conceptual model of measures implemented to manage arisings and runoff;
- A. Arisings from the launch / reception pit, or any other significant excavation (e.g., cable joint bays), will be directed the treatment train.
- B. Arising control area i.e., a temporary bund. Gross solids will be temporarily deposited here. Water arising with the material will be allowed to drain to sump.
- C. Sump / Pump. Sump will discharge by gravity / pumped to stilling pond.
- D. Temporary stilling pond. This can be constructed using soils for bunding in combination with an impermeable liner.
- E. The outfall from the stilling pond will be buffered (coarse aggregate) to dissipate energy and diffuse discharging water.
- F. Silt Screen. A silt screen will be in place down gradient of the Stilling Pond outfall. This is a precautionary measure to mitigate peak loads or surcharges in the system.
- G. Monitoring Location/s. Discharge quality will be monitored in real time using telemetry systems. Monitoring of discharge quality will be carried out at the outfall of the stilling pond i.e., before being actually discharged to surface vegetation or surface water (licensed).
- H. Sump / Pump. Discharge By-Pass. If water discharging from the stilling pond exceeds quality reference limits water will be diverted (pumped) from the stilling pond to the settlement / treatment tank.
- I. Stilling Pond By-Pass. Similar to Discharge By-Pass, if conditions dictate water can be diverted directly to Settlement / Treatment Tank.
- J. Settlement / Treatment Tank. A settlement tank will in line and ready to use if required i.e., water quality at stilling pond outfall fails to meet quality reference limits. The tank will be equipped with treatment systems which will be activated as the need arises, for example; very fine particles which are very slow to settle can be treated with a flocculant agent to promote settlement of particles.
- K. GAC Vessel/s. As a precautionary measure, GAC (Granulated Activated Carbon) vessel/s will be in line and ready to use if required. GAC vessels are used to filter out low concentrations of hydrocarbons. Significant hydrocarbon contamination is only envisaged under accidental circumstances. If a hydrocarbon spill does occur, normal operations will pause and the treatment train will be utilised to remediate captured contaminated runoff.
- L. GAC Vessel By-Pass. If the quality of the water is acceptable in terms of hydrocarbon contamination.
- M. Treated water will be discharge by gravity / pump to the stilling pond for additional clarification, monitoring and buffered discharge to vegetated area.
- N. Silt Bag. A silt bag can be used as alternative to stilling ponds. However, silt bags must only be used as primary method in lower risk areas i.e., outside of buffer zones, etc. Stilling ponds will be the primary method (D, N) is circumstances where risk is elevated, however a gate valve and silt bag can be included in the treatment train and used as an emergency discharge route in the event that the stilling pond needs remediation or maintenance.
- In all instances, stilling ponds (D), Silt Bags (N) and outfalls (E) will be situated outside of surface water buffer zones. At many locations, particularly at HDD locations works will be within buffer zones. In these instances, the treatment train can be positioned upgradient along the road where discharge to vegetated areas / roadside drains can be managed.

Site Name: Outfield Wind Farm Project, Co. Clare	Project No. 604569	Drawn By: Sven Klinkenbergh Principal Environmental Consultant
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 14 Treatment Train Layout for Active Runoff Management (e.g. HDD)	Client: Orsted Renewables Ltd	
	Date: 07/11/2023	Reviewed By: SK
	Revision: 00 DRAFT	



Conceptual Dewatering and Treatment Train Flow Diagram

Contaminated water arising from construction works, namely; excavations and temporary stockpiling, will be contained and treated prior to release or discharge. The schematic presented here is a conceptual model of measures implemented to manage arisings and runoff.



Site Name:
Oatfield Wind Farm Project, Co. Clare


Figure Name:
**Appendix 9.5 – Conceptual & Information Graphics – Tile 15
Conceptual Dewatering and Treatment Train Flow Diagram**

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00 DRAFT

Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
Reviewed By:	SK




Full Isolation Over Pumping – Plan



NOTES:

- Full isolation over pumping / siphon. A whole section of the channel is isolated using barriers that span the full width of the river. This keeps a stretch of the river dry and the water is transferred downstream of the works area by mechanical assistance (pumping or siphon). The pump and associated pipework need not be located in the isolated area.
- This method is the preferred method for channel diversion during instream works, for example, during watercourse crossing / culvert construction. However, the pumping equipment deployed must be capable of the surface water feature discharge rate, including backup equipment and fail safe protocols.

Full Isolation by Diversion – Plan




NOTES:

- Full isolation temporary diversion channel. A whole section of the channel is isolated and kept dry, and the water is transferred downstream of the works area by excavating a temporary open channel.
- This is the less preferred method due to the destructive nature of constructing temporary diversion channels. However, in some instances where discharge rates are high, this method will negate the requirement for large volume pumping and associated inherent risks.


SEPA (2009) Engineering in the Water Environment Good Practice Guide – Temporary Construction Methods.

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Sven Klinkenbergh Principal Environmental Consultant	
	Client:	Orsted Renewables Ltd			
Figure Name: Appendix 9.5– Conceptual & Information Graphics – Tile 16 Isolation and Over Pumping of Watercourses– General Considerations	Date:	07/11/2023	Reviewed By:	SK	
	Revision:	00 DRAFT			

Temporary barrier fabric used to retain erosion of sand, silt, and clay. Geotextile silt fencing acts as a vertical, permeable, interceptor to sediment-laden waters from construction.



Conceptual graphic of a silt fence
Tech Weave (2020) Available at: <<https://techweave.com/silt-fences/>>



Conceptual graphic of a silt fence
Available at: <<https://www.pub.gov.sg/Documents/SiltFences.pdf>>




Example of Silt fencing in use
(EnviroPro, 2022) Available at: <<https://www.enviropro.co.uk/entry/153977/Siltbuster/Terrastop-silt-fences-for-erosion-and-runoff-control/>>



Example of Silt fencing in use
Bowman Construction Supply (2023) Available at: <<https://www.bowmanconstructionsupply.com/products/silt-fence/>>

Silt fences control runoff by allowing water to pass through the fabric while collecting leftover sediment.


Site Name: Oatfield Wind Farm Project, Co. Clare	Project No. 604569	Drawn By: Colleen McClung Graduate Project Scientist	
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 17 Silt Fencing	Client: Orsted Renewables Ltd		
	Date: 07/11/2023		
	Revision: 00		



Example of a Strawbale Checked Dam
Robichaud, et al. (2019)



Example of a Strawbale Checked Dam
(Kawartha Conservation, 2020)



Conceptual graphic of a straw bale checked dam
(Storrar, 2013)

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No. 604569	Drawn By: Colleen McCung Graduate Project Scientist
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 18 Examples of Mitigation Measures to Reduce Sediment Transport	Client: Orsted Renewables Ltd	
	Date: 07/11/2023	Reviewed By: Sven Klinkenbergh Principal Environmental Consultant
	Revision: 00	

Project No. 604569	Drawn By: Colleen McCung Graduate Project Scientist
Client: Orsted Renewables Ltd	
Date: 07/11/2023	Reviewed By: Sven Klinkenbergh Principal Environmental Consultant
Revision: 00	

Project No. 604569	Drawn By: Colleen McCung Graduate Project Scientist
Client: Orsted Renewables Ltd	
Date: 07/11/2023	Reviewed By: Sven Klinkenbergh Principal Environmental Consultant
Revision: 00	






Example of buffered outfall with coarse aggregate
(Catchments and Creeks Pty Ltd., 2020)



Example of a silt bag
(Cascade Geotechnical Inc., 2022)



Conceptual graphic of a discharge to vegetated outfall
(Janes-Bassett *et al.*, 2016)

Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Colleen McCung Graduate Project Scientists
	Client:	Orsted Renewables Ltd		
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 19 Examples of Mitigation Measures to Reduce Sediment Transport	Date:	07/11/2023	Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant
	Revision:	00		





Example of a temporary spill pallet bund (Road Ware, 2023)
 Available at: <https://www.roadware.co.uk/gsp2ibc-galvanised-steel-double-ibc-spill-pallet-bund/?gclid=Cj0KCQiA8aOeBhCWARIsANRFRQGFh5e3lU9TcfrIXMacEnilL05gFmK1b0_dHBi7MRklwiM0cU7F2oaAkDSEALw_wcB>

Example of a temporary spill pallet bund (Road Ware, 2023)
 Available at: <https://www.roadware.co.uk/ibc-storage-tank-pallet-spill-containment-bund-stand/?sku=IBCSP&gclid=Cj0KCQiA8aOeBhCWARIsANRFRQFTsDISEUrK4rdov4TcTBQOwnZguishep9-yj6_qx9NexUXnAv6ONkaAq8ZEALw_wcB>



Example of a temporary spill pallet bund (Road Ware, 2023)
 Available at: <https://www.roadware.co.uk/bp4c-covered-4-drum-spill-pallet-bund-ump/?gclid=Cj0KCQiA8aOeBhCWARIsANRFRQFNE1gbC8i9OUP2HLpHeKcFDNjrurp_ui5Nz6mRa1WbINXRH17di8aAn-kEALw_wcB>

Site Name: Outfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By: Colleen McClung Graduate Project Scientist	
	Client:	Orsted Renewables Ltd		
Figure Name: Appendix 9.5 – Conceptual & Information Graphics – Tile 20 Examples Environmental ‘Good Practice’ of Bunded Materials	Date:	07/11/2023	Reviewed By: Sven Klinkenbergh Principal Environmental Consultant	
	Revision:	00		




Meeds Environmental, LLC, 2012
 <<http://www.meedsenvironmental.com/wheel.php>>



Neptune Wash Solutions, 2023
 <<https://www.neptunewash.com/automated-wheel-wash-systems/>>



Construction.co.uk, 2023
 <<https://www.construction.co.uk/c/217313/wheel-wash-ltd>>



KKE Corporation, 2023
 <<https://kkewash.com/en-gb/8-4-agc-portable-tire-wash/>>

Site Name:
Oatfield Wind Farm Project, Co. Clare


Figure Name:
Appendix 9.5 - Conceptual & Information Graphics – Tile 21 Wheel Washout Station

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00


Drawn By:	Colleen McClung Graduate Project Scientist
Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant



Existing Drainage Scenario



Proposed Drainage Scenario



Site Name:
Oatfield Wind Farm Project, Co. Clare

Figure Name:
Appendix 9.5 – Conceptual & Information Graphics – Tile 22
Examples of Conceptual Hardstand – Plan

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	03/05/23
Revision:	02

Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
Reviewed By:	SK




Graphics & Design for consideration at detailed design phase and engineered specification of required infrastructure. Not to scale.

Artificial drainage networks cut throughout peatlands reduce the water table and impeded the reestablishment of Sphagnum moss (the acrotelm/uppermost layer in peat bogs) which is capable of hold over 20 times its dry weight in water

Rainfall is no longer absorbed/held up on Site and is lost to surface water receptors as runoff. This can lead the erosion and entrapment of exposed peaty soils.



(Pre-Development)
Existing Track Surface Level




Subsoil berms act as barriers to retain peat deposits within specified areas around turbine hardstands.

Restorative mitigation measures aim to improve the hydrological regime of the Site while creating conditions more favorable for the recolonization of Sphagnum mosses / reestablishment of an upper acrotelm layer.

Historic drainage network is blocked which reduces the runoff and facilitates rewetting of previously degraded peatland.

(Post-Development)
Existing Track Surface Level



Site Name:
Oatfield Wind Farm Project, Co. Clare


Figure Name:
**Appendix 9.5 – Conceptual & Information Graphics – Tile 23
Peat Deposition Areas – Linear view**


Project No.	604569
Client:	Orsted Renewables Ltd
Date:	03/05/23
Revision:	02

Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
Reviewed By:	SK




- The three principal materials excavated in order of depth will include topsoil at the surface, subsoils, and weathered and broken bedrock (Horizons A-C, respectfully).
- On receipt of consent, a geotechnical site investigation will be undertaken, including trial pitting to obtain higher resolution data on soil stratigraphy and soil types.
- A suitably qualified geotechnical / soil scientist will supervise all excavation and the principal material types (topsoil, subsoil and bedrock) will be segregated as they arise.
- Temporary storage locations and stockpiled arisings will be managed in such a way that as to not mix individual soils types which will, in turn will facilitate reuse on Site. Some measures which will be taken include;
 - Designated areas for each type of material which will be adequately sized based on Material Balance Assessment calculations and planned storage height.
 - Incorporating the planned movement of materials for example; Topsoil will be the first material to be excavated and the last to be used in reinstatement.
 - Adequate space between stockpiles to reduce the potential of mixing when material is being deposited or removed, or if localized stability issues arise for example; stockpile collapse.
 - It is also important to mitigate against the entrainment of solids in runoff (EIAR Chapter 9 – Hydrology & hydrogeology).
- In order to reduce the amount of arisings to be managed or stored at any one time during the construction phase, a Materials Balance Assessment and Materials Management Plan will be developed with a view to identifying suitable locations for permanent reinstatement as early as possible, for example; as the construction phase progresses, opportunities to move arisings to a permanent reinstatement area in one movement will be taken as often as possible.
- Backfilling in layers will be carried out at the designated reinstatement locations, this will include; use of material as fill under infrastructure, backfill around newly installed infrastructure e.g. foundations, and potentially in improvement areas.
- Infilling with material in identified soil horizons to revert these areas to baseline levels.



Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Colleen McClung Graduate Project Scientist	
	Client:	Orsted Renewables Ltd			
Figure Name: Appendix 9.5 - Conceptuel & Information Graphics – Tile 24 Conceptual Soil Horizon Graphic	Date:	07/11/2023	Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant	
	Revision:	00			


- All stockpiles will be covered with high-grade polythene sheeting to prevent run-off of rainwater and leaching of potential contaminants from the stockpiled material generation and/or the generation of dust.
- Recovered material destined for reuse off site will comply with Article 27 or Article 28 of the EPA to be classified as a by-product or as end-of-life waste, or Certificate of Registration for topsoil.
- Excess soils which cannot be reused will be tested and classified as a waste and disposed of appropriately.
- Temporary stockpiles will avoid areas on Site near artificial drainage channels (outside designated surface water buffer zones) and will adhere to mitigation measures outlined in **EIAR Chapter 9 Hydrology and Hydrogeology**, in particular in dealing with entrainment of soils in surface water runoff.



Site Name: Oatfield Wind Farm Project, Co. Clare	Project No.	604569	Drawn By:	Colleen McClung Graduate Project Scientist
	Client:	Orsted Renewables Ltd		
Figure Name: Appendix 9.5 - Conceptual & Information Graphics – Tile 25 Conceptual Management of Stockpiles Graphic	Date:	07/11/2023	Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant
	Revision:	00		



Two Historic Wells (W!)



A historic feature indicated in Cassini 6 inch map, located outside the blue line boundary.

Figure 15 - Historic Surface Water Feature Cassini 6-inch map


- Legend**
- Project related data**
 - Site Layout V04**
 - Blue line boundary**
 - ORS_BLB_Rev01
 - Grid connection Route**
 - ORS GC LoopIn1 Rev07
 - Design_Grid_Connection_Ardacrusha
 - ORS GC Drumline Rev07
 - Base Layers**
 - OpenStreetMap

Project ID	604569
Project Name	Orsted WW
Projection	ITM
Drawn by	CCa
Reviewed by	JS
Version	25/10/2023

References/Sources:
 Environmental Protection Agency (EPA)
 Geological Service Ireland (GSI)
 Bing Aerial / Google / Open Street Map / Google Roads
 Global Digital Elevation Model (GDEM)



Note: Data points presented are georeferenced using open source data and/or a handheld GPS. This drawing / map is considered a conceptual model with reasonable accuracy for the purposes of environmental assessment. This drawing should not be relied upon for detailed design purposes.




Site Name: Oatfield Wind Farm Project, Co. Clare
Figure Name: Appendix 9.5 - Conceptuel & Information Graphics – Tile 26 Historic Surface Water Feature Cassini 6-inch map


Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00

Drawn By:	Jayne Stephens Project Scientist
Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant





Site Name: Oatfield Wind Farm Project, Co. Clare	Project No. 604569	Drawn By: Sven Klinkenbergh Principal Environmental Consultant	
	Client: Orsted Renewables Ltd		
Figure Name: Appendix 9.5 - Conceptuel & Information Graphics – Tile 27 Management of Excavation Arising – Phased Approach 1	Date: 07/11/2023	Reviewed By: Sven Klinkenbergh Principal Environmental Consultant	
	Revision: 00		




Site Name:
Oatfield Wind Farm Project, Co. Clare

Figure Name:
**Appendix 9.5 - Conceptuel & Information Graphics – Tile 28
 Management of Excavation Arising – Phased Approach 2**

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00

Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant






Site Name:
Oatfield Wind Farm Project, Co. Clare

Figure Name:
**Appendix 9.5 - Conceptuel & Information Graphics – Tile 29
 Management of Excavation Arising – Phased Approach 3**

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00

Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant






Site Name:
Oatfield Wind Farm Project, Co. Clare

Figure Name:
**Appendix 9.5 - Conceptuel & Information Graphics – Tile 30
 Management of Excavation Arising – Phased Approach 4**

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00

Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant





Site Name:
Oatfield Wind Farm Project, Co. Clare

Figure Name:
**Appendix 9.5 - Conceptuel & Information Graphics – Tile 31
 Management of Excavation Arising – Phased Approach 5**

Project No.	604569
Client:	Orsted Renewables Ltd
Date:	07/11/2023
Revision:	00

Drawn By:	Sven Klinkenbergh Principal Environmental Consultant
Reviewed By:	Sven Klinkenbergh Principal Environmental Consultant

